

Instructions and Adjustments

Part No. TS3020  
NOMAD™ Economy Welding Table


Owner's Manual




Part No. TS3020

» Tools required for assembly : wrenches, phillips screwdriver and pliers.


Installing Tabletop and Steel Guide Rails (Fig. 12-15)




13. Carefully turn entire Table Top assembly right side up. Place the 6mm Washer (**S1**) on the threaded stud of the Lock Lever (**P**). Repeat on all four Lock Levers.



14. Attach the Guide Rails (**N & O**) to the table using the Lock Levers (**P**).




15. Insert the Pull Handle (**U**) into the holes located on the 30" side of the tabletop. Fasten to the tabletop using the Springs (**V**), 8mm Washers (**S2**) and 8mm Lock Nuts (**R2**), and tighten.



The Nomad Economy Welding Table now is fully assembled.


Storing and Adjusting the Nomad Economy Welding Table

Moving the Table




Loosen Locking Handle. Fold tabletop down to completely vertical position. Push legs in to closed position. Lean the table back on the two casters, and use the pull handle to move the table.

Adjusting the Table Height



Loosen Plastic Knobs (**L**). Remove Locating Pins (**K**). Grasp tabletop and lift (evenly) to desired height. Re-insert Locating Pins and tighten Plastic Knobs.

Stabilizing the Table



Adjust cam operated Eccentric Leveling Foot (**C1**) for stabilizing the table on uneven surfaces! Turn the wheel clockwise to elevate, and counterclockwise to lower the table.

Maintenance

Keep the table clean for optimal performance. Wipe away dust and debris from the tabletop and legs.

Safety

ALWAYS wear safety goggles, gloves, and other appropriate safety items for protection. Use the table only for it's intended purpose. NEVER stand on the table. Do not drop the table, throw it, or otherwise misuse the table.

Limited 1 Year Warranty

Each STRONG HAND TOOL® product is warranted to be free from defects in material and workmanship. Return to place of purchase for a replacement if warranty applies.



8750 Pioneer Blvd, Santa Fe Springs, CA 90670 U.S.A. | [www.stronghandtools.com](http://www.stronghandtools.com)  
Toll Free : 800.989.5244 | Tel : 562.949.8625 | [sales@stronghandtools.com](mailto:sales@stronghandtools.com)

The **NOMAD**™ Economy Welding Table

Contents:

- » Parts List
- » Assembly Instructions
- » Adjustments
- » Maintenance
- » Safety
- » Warranty



Specifications:

Part No.	Tabletop Size	Table Height Range	Slots in Tabletop	Table Positions	Load Capacity	Weight
TS3020	30" W x 20" L (760 x 510 mm)	26" ~ 32" (660 ~ 810 mm)	1.1" (28 mm)	Horizontal, 30°, Folded	350 lbs. (160 kg)	43 lbs. (20 kg)


Parts List

Part No. TS3020  
NOMAD™ Economy Welding Table

Assembly Instructions


Part No. TS3020  
NOMAD™ Economy Welding Table

Item		Qty	Item		Qty
A	Steel Table Top (30" x 20")	1	N	Guide Rail, 30"	1
B	Table Leg Assembly	1	O	Guide Rail, 20"	1
C	Table Leg with Tool Shelf	1	P	Lock Lever	4
C1	Eccentric Leveling Foot	1	T	Crossbar	1
U	Pull Handle	1	Q1	Pan Head Screw 6mm x 40mm	6
V	Compress Spring	2	Q2	Hex Head Bolt 8mm x 20mm	4
D	Joint	2	Q3	Hex Head Bolt 8mm x 40mm	2
E	Height Adjustment Post	2	Q4	Hex Head Bolt 8mm x 50mm	4
F	Angle Adjustment Plate	2	Q5	Hex Head Bolt 8mm x 55mm	2
G	Locking Handle	2	R1	Lock Nut 6mm	6
K	Locating Pin	2	R2	Lock Nut 8mm	8
L	Plastic Knob	2	R3	Hex Nut 8mm	6
M1	Caster	2	S1	Washer 6mm	10
M2	Caster Mounting Bracket	2	S2	Washer 8mm	14




» Tools required for assembly : wrenches, phillips screwdriver and pliers.


Setting up the Leg Assembly (Fig. 1-6)




1. Place the Leg Assembly (**B** & **C**) onto the Joint (**D**) and fasten with the 8mm x 50mm Hex Head Bolts (**Q4**). Do not over-tighten and make sure the leg assembly is free to pivot.



2. Slightly open the Table Legs.




3. Position the Leg Assembly on its side to attach the Casters.




4. Mount the Casters Brackets (**M2**) on Table Leg Assembly (**B**) using two 6mm x 40mm Pan Head Screws (**Q1**), and two 6mm Lock Nuts (**R1**). Repeat on the other side.


Setting up the Leg Assembly (Fig. 1-6)




5. Attach the Casters (**M1**) onto the brackets using the 6mm x 40mm Pan Head Screws (**Q1**), and one 6mm Lock Nut (**R1**) and one 6mm Washer (**S1**).



6. Make sure wheels can spin freely and repeat on other side. Position the leg assembly right side up to attach the Height Adjustment Posts.




7. Attach Angle Adjustment Plate (**F**) to the Height Adjustment Post (**E**) using one 8mm x 40mm Hex Head Bolt (**Q3**), one 8mm Washer (**S2**) and one 8mm Lock Nut (**R2**).




8. Attach Locking Handle (**G**) to Angle Adjustment Plate (**F**) through the 8mm square nut on the Height Adjustment Post (**E**).


Height Adjustment Post (Fig. 7-11)




9. Insert the Height Adjustment Post through the Joint (**D**) and secure with Locking Pin (**K**) and the Plastic Knob (**L**).



10. Repeat on the other side and tighten all screws. Make sure both height posts are at the same height.



11. Install Crossbar (**T**) using one 8mm x 55mm Hex Head Bolt (**Q5**), 8mm Washer (**S2**) and 8mm Hex Nut (**R2**). Repeat on the other side and tighten bolts.



12. Place Table Top upside down. Install Angle Adjustment Plates using two 8mm x 20mm Hex Head Bolts (**Q2**) and 8mm Hex Nuts (**R3**). Tighten screws.